

Webasto Coolant Heater

The Webasto coolant heater used in all Idle Free eAPUs requires minimal maintenance. Please follow the simple steps below to ensure your heater is ready to go this winter.

- Remove the cover from the frame rail unit and inspect the heater for obvious wear and damage.
- Clean debris from the heater with compressed air
- Inspect wiring harnesses for damage and repair or replace if necessary
- Inspect battery connections, clean and treat with anti-corrosion spray
- Check air intake and exhaust for obstructions
- Inspect all coolant lines and clamps for tightness and leaks
- Inspect fuel line for damage and check all clamps for tightness. **Replace fuel filter every year**
- Start the heater and let it run for 15 minutes to insure it is functioning properly.



Note: It is recommended to run the heater for 15 minutes every month of the year

Remember, we are always just a phone call or email away to help you.

- Tech Support Phone: (920) 206-9333
- Tech Support email: techsupport@idlefreesystems.com